

# HOME DECORATORS


## *collection*<sup>®</sup>

BF-24807 RIBBON STORAGE 21"W DOUBLE ROD

INV#07955











### ASSEMBLY INSTRUCTIONS

Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  LEFT SIDE PANEL-1PC	<b>C</b>  RIGHT SIDE PANEL-1PC
<b>D</b>  BACK PANEL-1PC	<b>E</b>  IRON RODS-2PCS	<b>F</b>  SCREWS-11PCS
<b>G</b>  NUTS-7PCS	<b>H</b>  SCREWS-2PCS	<b>I</b>  HANGERS-2PCS
<b>J</b>  ALLEN WRENCH-1PC		


**NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.**



HOW TO USE THE ALLEN WRENCH


### 1) . ASSEMBLE THE BACK PANEL (D).

- INSERT THE 4 NUTS(G) INTO THE HOLES IN THE BACK PANEL(D) .
- ATTACH THE SIDE PANELS(B/C) TO BACK PANEL(D) USING 4 SCREWS(F) .



### 2) . ASSEMBLE THE TOP PANLE(A).


- INSERT THE 3 NUTS(G) INTO THE HOLES IN THE BACK PANEL(D) .
- ATTACH THE TOP PANEL(A) TO SIDE/BACK PANELS(B/C/D) USING 7 SCREWS(F) .



### 3) . ASSEMBLE IRON RODS(E) .

- INSERT THE 2 IRON RODS(E) INTO THE HOLES IN THE SIDE PANELS(B/C) .

WHEN INSTALLED, PLEASE PUT THE IRON RODS(E) IN IT FROM THE RIGHT SIDE PANEL(C) THEN PUT IT INTO THE LEFT SIDE PANEL(B) . WHEN DISMANTLED, PLEASE REMOVE THE LEFT SIDE PANEL(B) .



#### 4) . ASSEMBLE THE HANGERS(I) .

- PUT 2 HANGERS(I) HIT INTO THE HOLES IN THE WALL AND ROTATE 2 SCREWS(H) INTO THE HANGERS(I) .